AUDIOVOX®
ELECTRONICS CORP.



D1805

PORTABLE 8" LCD MONITOR AND DVD PLAYER

A. Introduction

Thank you for selecting the D1805 portable DVD player. The main features include a 8" Wide Screen (16:9 Aspect Ratio) Liquid Crystal Display (LCD) monitor and a DVD player. The unit applies the latest state of the art electronics and is designed for use in hotels, offices, vehicles or your home. The unit is constructed to provide years of reliable, trouble-free service, and is compact so that you can take it with you anywhere and is designed for quick and easy installation. Please read the entire instruction manual supplied with this product prior to operation. The documentation will assist you in installing the system properly to obtain the best equipment performance. Please treat this manual proplely for later use.

B. Cautions and Warnings

1. Placement

To prevent fire or electric shock, do not expose this appliance to rain or moisture. Do not place the set on an unstable cart, stand, tripod, bracket or table to prevent it from falling. Keep the unit away from strong magnets, heat sources, direct sunlight, excessive dust. If the unit is brought directly from a cold to a warm location, moisture may condense inside the unit. When you move it from a cold to a warm location, wait for about one hour before operating the unit, or remove the disc and leave the unit turned on until the moisture evaporates.

2. Installation

Ensure that the D1805 is installed in accordance with the instructions and illustrations provided in this manual.

3. Object and Liquid

Do not push objects of any kind into the unit through openings; do not spill or spray liquid of any kind on or in the system (this may result in a fire or electric shock). Do not place anything heavy on the unit. To ensure proper ventilation and proper operation, never cover or block the slots and openings with a cloth or other material.

4.Disassemble

Do not attempt to disassemble the cabinet. There is a risk of electric shock and/or exposure to Laser Radiation. Contact qualified service personnel if your system is in need of repair.

5. Cleaning Unit

When cleaning, make sure the system is unplugged from the power source. Do not use liquid cleaners or aerosol cleaners. Use a cloth lightly dampened with water for cleaning the exterior of the system only.

6. Disc

Do not use irregularly shaped discs such as heart or star-shaped discs as they may cause the unit to malfunction. Do not stick paper, tape or glue on the disc. Do not expose the disc to direct sunlight or heat sources such as hot air ducts. Do not touch the surface of disc. Handle the disc by its edge. Clean the disc by wiping the disc from the center out with a cleaning cloth. Remove the disc from the unit and store it in its case after playing. Some playback operations of discs may be intentionally fixed by software producers. Since this unit plays discs according to the disc contents the software producers designed, some playback features may not be available. Also refer to the instructions supplied with the discs.

C. Contents

1. 1 x 8'' LCD Monitor & DVD Player Combo
2. 1 x AC to DC Adapter
3. 1 x Rechargeable Battery
4. 1 x Remote Control with battery
5. 1 x Instruction Manual
6. 1 x AV Cable
7. 1 x DC Power Adapter

D. Powering and installation

1. Powering the system indoors (Refer to Figure 1)

Plug one end of the AC to DC adapter into the DC 9V jack on the left side of the main unit, then plug the other end into the 120V AC power socket.

2. Powering the system in a car (refer to Figure 1)

Plug one end of the DC Power adapter into the DC 9V jack on the unit, then plug the other end into the cigarette lighter socket.



1 **2**

Figure 1

E. Controls, Indicators, and Connectors

1. Unit View (Refer to Figure 2)

1) DC 9V Input Jack
2) Audio Jack (L+R)
3) Video Jack
4) AV Input /Output Switch
5) Brightness Control
6) MENU
7) Up button
8) Left Button
9) OK Button
10) Down Button
11) Right Button
12) Close disc cover point
13) Open Button
14) Previous Button
15) Stop Button
16) Next Button
17) Play Button
18) Pause Button
19) Screen Mode (wide) Button
20) Power Saving Mode Switch
21) NTSC/PAL Switch
22) Coaxial Jack
23) Hi-Fi Headphone Jack
24) Volume Control
25) Power On/ Off Switch
26) Remote Control Sensor
27) Power LED
28) Battery Clips
29) Battery Connector



Figure 2

2. Remote Control View (Refer to Figure 3)

1) Display Button
2) Angle Button
3) Subtitle Button
4) Audio Button
5) Zoom Button
6) UP/DOWN/LEFT/RIGHT/ ENTER Buttons
7) Return Button
8) A-B Button
9) Forward Button
10) Reverse Button
11) Slow Button
12) Stop Button
13) Number Buttons
14) Setup Button
15) Menu Button
16) Repeat Button
17) SKIP-
18) SKIP+
19) Play Button
20) Pause Button



Figure 3

F. Loading and Playing a Disc

a. After connecting power to the unit, Slide the power switch to the "ON" position, the power indicor will illuminate red.
b. Open the disc tray by pressing OPEN , and place a disc into the tray with the labal side facing up.
c. Close the tray with pressing "PRESS" button.The unit will load the disc and start playing by pressing "PLAY".
d. Rotate the BRIGHT and VOLUME Controls to adjust the LCD's brightness and the DVD player's volume.
e. To stop playing a disc, press STOP.

G. SETUP

Press 'SETUP' to display the Main screen of the SETUP Menu on the screen. Press 'SETUP' again to exit the SETUP Menu and the unit will resume it's last playback mode.

Figure 7. Main SETUP Menu Screen

1) Press "Setup", the 'GENERAL SETUP PAGE' will display on screen.

Figure 8. SPDIF Output Screen

a). Select "SPDIF Output" using the DOWN button, Then, press "Right" enter the Submenu, select SPDIF OFF, SPDIF/RAW, SPDIF/PCM by press UP/DOWN and confirm the setting by Enter. Press LEFT to return.
* SPDIF OFF: the digital signal Audio output is off.
* SPDIF/RAW: the signal output from"COAXIAL".
* SPDIF/PCM: the signal output will be pulse code Modulation

b). Select TV DISPLAY using the DOWN button, and then press RIGHT to enter the submenu. Select the TV display mode on the screen using UP/DOWN, and press ENTER to confirm the setting. Press LEFT to return.

* NORMAL/PS: When the player is connected to a normal TV, and a wide picture is shown on the full screen.
* NORMAL/LB: When the player is connected to a normal TV, and a wide picture is shown on the screen with a black strip at both the top and bottom of the screen.
* WIDE: When the player is connected to a wide screen TV, a wide picture is shown on the full screen.

Figure 9. TV DISPLAY Screen Display

c).Select 'ANGLE MARK' using the DOWN buttton, and then press the RIGHT button to enter the submenu. Choose Angle Mark on or off using the UP/DOWN buttons and then press ENTER to confirm the setting. Press the LEFT button to return.

Figure 10. ANGLE MARK Screen Display

* ON: The screen will show the angle mark icon. (*If an angle option is available).
* OFF: The screen will not display the Angle Mark

NOTE: Not all discs contain above features.

d). Select ‘SCREEN SAVER’ using the DOWN button.

Figure 11. SCREEN SAVER Display

*ON: enables screen saver

*OFF: disables screen saver (off)

***NOTE:** The DVD player will enter the Screen Saver mode after approximately five minutes if the same image remains on the screen.

e). Select “ Last Memory” using the DOWN button.

Figure 12. LAST MEMORY Screen Display

*on: The unit will return to the last position on the disc.

*off: The unit will not return to the last position on the disc.

2) With no disc inside the player select “Video quality Setup”by using the LEFT/RIGHT buttons, press “enter” to enter the video quality set up page.

Figure 13. Main SETUP Menu VIDEO QUALITY

a).Select “Brightness by using the UP or DOWN buttons ,then press “Enter”you can change the Brightness by pressing the LEFT or RIGHT buttons. To exit “Brightness Setting”, press “Enter”again to return to the main Menu.



Figure 14. BRIGHTNESS Screen Display

b).Select “Contrast” by using the UP or DOWN buttons,then press “Enter” you can adjust the Contrast by pressing the LEFT or RIGHT butttons.



Figure 15. CONTRAST Screen Display

To exit “Contrast” Setting, press “Enter”again to return to the main Menu.

c).Select “Hue” by using the UP or DOWN buttons, then press “Enter” you can adjust the Hue by pressing the LEFT or RIGHT buttons.



Figure 16. HUE (Tint) Screen Display

To exit “Hue”Setting,press “Enter”again to return to the main Menu.

d).Select “Saturation “ by using the UP or DOWN buttons, then press “Enter” you can adjust the Saturation by pressing the LEFT or RIGHT buttons.



Figure 17. SATURATION(Color) Screen Display

To exit “Saturation”Setting,press “Enter”again to return to the main Menu

3).With no disc inside the player ,select “password” using the LEFT or RIGHT buttons, then press the ENTER button to enter the submenu .

Figure 18. PASSWORD CHANGE Menu

Press ‘ENTER’ to enter the Password Change Page. Input the Old Password or the Default Password, the New Password, and the Confirmed New Password. Press ‘ENTER’ to confirm the change.

Figure 19. PASSWORD CHANGE MENU

NOTE: The Default Password is ***3308***. This password is always effective even after you have selected your own password and changed it. To avoid the possibility of others using the default password to set the parental level and change the password, you can record this default password in another area and delete it from this manual. Some discs can be limited depending on the age of users while some discs cannot.

Figure 17. PASSWORD VERIFY Input Screen Display

4). With no disc inside the player select 'PREFERENCES' using the LEFT or RIGHT buttons, then press 'ENTER' to enter the preferences page.

Figure 18. Preference Audio Language

a. Select 'AUDIO' using the UP/DOWN buttons, then press 'RIGHT' to enter the submenu. Select the audio language you desire using the UP or DOWN buttons, then press 'ENTER' to confirm the setting. Press LEFT to return.

b. Select ‘SUBTITLE’ the using the UP or DOWN buttons, then press RIGHT to enter the submenu. Select the desired subtitle language or SUBTITLE OFF using the UP or DOWN buttons , then press ‘ENTER’ to confirm the setting. Press ‘LEFT’ to return.

Figure 19. Preference SUBTITILE LANGUAGE

c. Select ‘DISC MENU’ using the UP or DOWN buttons, then press ‘RIGHT’ to enter the submenu. Select the Disc Menu Language you desire using the UP or DOWN buttons , then press ‘ENTER’ to confirm the setting. Press ‘LEFT’ to return.

Figure 20. Preference DISC MENU LANGUAGE

Note: Language and subtitle selection is only available for discs that are recorded in the above listed languages. If the selected, language is not available, the player will play and display on the screen the original recorded language contained in the disc.

d. Select ‘PARENTAL’ using the UP or DOWN buttons , then press RIGHT to enter the submenu.



Figure 21. PARENTAL Preference Screen Display

Select the parental level you desire using the UP or DOWN buttons for discs with lock-out function or multiple rating levels. These are listed from the lowest level (1 Kid Safe) to the highest level (Adult). Enter a 4 digit password, then press ‘ENTER’ to confirm the parental level setting.
NOTE: The level of 8 Adult is the factory default.

e. Select ‘DEFAULTS’ using the UP or DOWN buttons, then press RIGHT to enter the submenu. Press ENTER to make the setting return to the factory-set mode.
NOTE: The parental setting is not affected by the default reset function.

Figure 22. Loading Factory Setting

1. Basic Operation

POWER	Turn the unit on/off
OPEN	Remove/load the disc
PLAY	Start Play/Execute item or setting
SLOW	Play at 1/2, 1/4, 1/8 or 1/16 times speed
PAUSE	Still Picture
STOP	(1 time) Stop at the present playing point / (2 times) Stop playing
NEXT	Go to the next chapter, track or scene during play back
PREVIOUS	Go back to the previous chapter, track or scene during play back
FORWARD	Scan forward at 2, 4, 8,16 or 32x times speed
REVERSE	Scan backward at 2, 4, 8, 16 or 32x times speed
LEFT/RIGHT/UP/DOWN	Used for Menu Navigation
ENTER	Execute item or confirm setting
NUMBERS	Select item or setting
RETURN	Return
MENU	Display the main menu of the disc
REPEAT	Repeat playing title, chapter, or track
A-B	Repeat a specific portion from point A to point B of the disc
DISPLAY	Display information (title, chapter, track, time, etc.).
ANGLE	Change the viewing angles on the scene
SUBTITLE	Select the subtitle language and turn it on/ off
AUDIO	Select the audio language
ZOOM	Enlarge an image to 2, 3, or 4 times the original size.
SETUP	Display the setup menu to select and set items, and exit the setup menu.

2. MENU

A DVD is divided into sections called titles and chapters. When you play a DVD, a root menu of the disc will appear on the screen of your TV or Monitor. The contents of the menu vary from disc to disc. Press MENU during playback to display the menu. Some DVDs only allow you to select disc playback options using the DVD root menu.

3. DISPLAY *(Display contents vary from disc to disc.)*

1. PLAYING TIME AND REMAINING TIME

a. During playback press the 'DISPLAY' button to display the current Title Number (1), the total Number of Titles (2), the current Chapter Number (3), the total Number of Chapters (4), and the Playing elapsed Time for the title (5). The heading will disappear automatically after 3 seconds if no buttons are pressed.



Figure 23. Title, Chapter Number, and Time Screen Display

b. Press 'DISPLAY' again to display the Remaining Time of the title. The heading will disappear automatically in 3 seconds.



Figure 24. Title Remaining Time Screen Display

c. Press ‘DISPLAY’ a 3rd time to display the Elapsed Time for the chapter. The heading will disappear automatically in 3 seconds.



Figure 25. Chapter Elapsed Time Screen Display

d. Press ‘DISPLAY’ a 4th time to display the Remaining Time for the chapter. The heading will disappear automatically in 3 seconds.



Figure 26. Chapter Remaining Time Screen Display

e. Press ‘DISPLAY’ a 5th time to exit, ‘DISPLAY OFF’ will be displayed and will disappear automatically in 3 seconds.

2. ANGLE

During playback of a disc, press ‘ANGLE’ to display the available angles for discs containing multi-angles*, with the current angle number (1) and the total number of angles (2) displaying. Press ‘ANGLE’ to select another angle, then press again to exit and return to the normal viewing angle. The angle display will disappear automatically if the ‘ANGLE’ button is not pressed again within 3 seconds.

***NOTE:** Not all discs contain this feature. This is indicated by the invalid icon.



Figure 27. Angle Screen Display

3. SUBTITLE

During disc playback press 'SUBTITLE' to select the subtitle language you desire*, with the current Subtitle Language Number (1) and the total Number of Subtitle Languages (2) displayed. If there are multiple languages press 'SUBTITLE' again to select another subtitle language. To turn subtitles OFF, press the 'SUBTITLE' button until 'SUBTITLE OFF' is displayed. The Subtitle display will disappear automatically if the 'SUBTITLE' button is not pressed again within 3 seconds.



Figure 28. Subtitle Screen Display

* Some DVDs only allow access to this function through the DVD menu.

4. AUDIO

During playback press 'AUDIO' to select the audio language you desire*, with the current Audio Channel Number (1) and the total number of Audio Channels (2) displayed. Press AUDIO again to select another audio language. The audio display will disappear automatically if the 'AUDIO' button is not pressed within for 3 seconds.



Figure 29. Audio Language Screen Display

* Some DVDs only allow access to this function through the DVD menu.

5. ZOOM

During playback press 'ZOOM' to enlarge the picture by 2x, 3x or 4X with the current zoom multiple.(1)Press "zoom"one time ,the picture will be enlarged 2X.(2)Press "zoom a "second time ,the picture will be enlarged 3X.(3)Press "zoom a "3rd time ,the picture will be enlarged 4X.(4)Press "zoom"4th time ,the picture will return to normal size.



Figure 30. ZOOM Screen Display

6. A-B REPEAT

a. During playback press ‘A-B’ to set the Starting Point A.



Figure 31. A-B Repeat Starting Point Screen Display

b. Press ‘A-B’ a second time to set the Ending Point B and the player will repeatedly play the part between Point A and Point B.



Figure 32. A-B Repeat Ending Point Screen Display

c. Press A-B a third time to cancel A-B repeat and resume playback.



Figure 33. A-B Repeat Cancelled Screen Display

7. REPEAT

a. During playback press 'REPEAT' once to repeatedly play the current chapter.

Figure 34. Chapter Repeat ON Screen Display

b. During playback press 'REPEAT' again to repeatedly play the current title.

Figure 35. Title Repeat ON Screen Display

c. During playback press 'REPEAT' a 3rd time to repeat all Chapters and Titles.



Figure 36. All Repeat ON Screen Display

d. Press “REPEAT” a 4th time, to resume normal play.



Figure 37. Repeat Off ON Screen Display

4. PLAYING AUDIO CDS

When playing an audio CD press the DISPLAY button on the remote to view time information. The options below show you what information is available using this function.

a. The current track and playing time of that track will be displayed on the screen.



Figure 38. SINGLE ELAPSED Screen Display

b. Press ‘DISPLAY’ one time and *SINGLE REMAIN* appears along with the current track playing and the amount of time left in that track.



Figure 39. SINGLE REMAIN Screen Display

c. Press 'DISPLAY' two times and *TOTAL ELAPSED* appears along with the current track playing and the total time that the CD has been playing.



Figure 40. TOTAL ELAPSED Screen Display

d. Press 'DISPLAY' three times and *TOTAL REMAIN* appears along with the current track playing and the amount of time remaining on the CD.



Figure 41. TOTAL REMAIN Screen Display

e. Press 'DISPLAY' four times and *" DISPLAY OFF"* will appear momentarily then disappear. The CD time Information will not be displayed.

USING THE REPEAT FEATURE

The default mode for the Repeat feature is OFF. Pressing REPEAT consecutively changes the repeat options:

- *TRACK*- repeats the track that is playing.
- *ALL*- repeats the disc that is playing.
- *OFF*

As you toggle through the options, the repeat option changes. The selected repeat option loops repeatedly until you turn it off.

5. PLAYING MP3 DISCS

MP3 is a format for storing digital audio. An audio CD-quality song is compressed into the MP3 format with very little loss of audio quality while taking up much less disc space. CD-R /RW discs that have been encoded in MP3 format are compatible with this system.

Playback modes:

FOLDER (normal playback)
SINGLE
REPEAT ONE (repeat playback of a song)
REPEAT FOLDER (repeat playback of a specific folder)

Insert an MP3 CD, the DVD player will initialize the disc and the directory (folder) will be shown on the TV screen.



Figure 42. MENU Screen Display

When an MP3 disc is inserted into the unit, the menu screen appears automatically. You can use the menu screen to change folders and songs. The system plays the songs in the order they were burned onto the disc.

1. Press the ▲ or ▼ button to choose a folder from the folder list on the left side of the screen.
2. Press ENTER to select the highlighted folder. The songs available under the folder will be listed.
3. Press STOP First, use ▲ or ▼ button to choose a song from the list. Press ENTER to select and begin playback of the highlighted song.

Use the ⏭ (NEXT) button to move to the next song. Press the ⏮ (PREVIOUS) button to move to the beginning of the previous song.

USING THE REPEAT FEATURE

The default mode for the Repeat feature is OFF. Pressing REPEAT consecutively changes the repeat options:

- SINGLE
- REPEAT ONE
- REPEAT FOLDER
- FOLDER

Pressing REPEAT the 5TH time will resume normal playback. As you toggle through the options, the repeat option changes. The selected repeat option loops repeatedly until you turn it off.

NOTICE

- " " icon in front of a file name indicates that this is a folder, not an MP3 file.
- "MP3" icon in front of a file name indicates that this is a MP3 file.

6. Playing JPEG file

1) Load the JPEG Disc into tray.
2) Select JPEG file by pressing “UP/DOWN” button.
3) You can preview the JPEG file by pressing “Play” or “ENTER”.
4) Pressing the left or right button will rotate the JPEG in that direction.
5) When browsing the photos, you can reverse the photo horizontally by pressing “Up” key,or you can reverse the photos vertically by pressing “Down” key.
6) When you browse the JPEG file, press “display”, there will be different refresh mode below.

a. Press “display” first time, “WIPE TOP” display on the screen, the picture will refresh from top to bottom.
b. Press “display” 2nd time, “WIPE BOTTOM” will display on the screen, the picture will refresh from bottom to top.
c. Press “display” 3rd time, “WIPE LEFT” will display on the screen, the picture will refresh from left side to right side.
d. Press “display” 4th time, “WIPE RIGHT” will display on the screen, the picture will refresh from right side to left side.
e. Press “display” 5th time, “DIAGONAL WIPE LEFT TOP” will display on the screen, the picture will refresh from left top to right bottom.
f. Press “ display ” 6th time, “DIAGONAL WIPE RIGHT TOP” will display on the screen, the picture will refresh from right top to left bottom.
g. Press “display” 7th time, “DIAGONAL WIPE LEFT BOTTOM” will display on the screen, the picture will refresh from left bottom to right top.
h. Press “display ” 8th time, “DIAGONAL WIPE RIGHT BOTTOM” will display on the screen, the picture will refresh from right bottom to left top.
i. Press “display” 9th time, “EXTEND FROM CENTER H” will display on the screen, the picture will refresh from horizontal center to both sides.
j. Press “display” 10th time, “EXTEND FROM CENTER V” will display on the screen, the picture will refresh from vertical center to both sides.

k. Press “display” 11th time, “COMPRESS TO CENTER H” will display on the screen, the picture will refresh from top and bottom to center.

l. Press “display” 12th time, “COMPRESS TO CENTER V” will display on the screen, the picture will refresh from right and left to center.

m. Press “display” 13th time, “WINDOW H” will display on the screen, the picture will refresh from four window’s top side to bottom side.

n. Press “display” 14th time, “WINDOW V” will display on the screen, the picture will refresh from four window’s left side to right side.

o. Press “display” 15th time, “WIPE FROM EDGE TO CENTER” will display on the screen, the picture will refresh from 4 edges to center.

7) When previewing the file, pressing “ANGLE, SUBTITLE, AUDIO, NUMBER, AB, RETURN, REW/FF, SLOW” a hand icon will appear on the display meaning that these options are not available.

8) Press “Stop” to browse the JPEG file, “SLIDE SHOW” “MENU” will display on the screen.

9) When browsing the picture, press “Stop” and thumbnail size picture will be diplayed. You can select the picture you desire by using the UP/DOWN/LEFT/RIGHT/ENTER key.

10) Press “Play” or “OK”, to preview the left top picture.

11) You can return the root Menu by pressing “left” key.

7. Playing a Video Game (Refer to Figure 44)

1. Slid the AV in/out button to the “In” position.
2. Plug the video output from your game system into the Audio and video input jack on the left side of the unit. Adjust the volume control and the brightness control on the monitor for individual preference.



Figure 44

8. Connecting to a TV or another monitor (Refer to Figure 44)

You can also connect the DVD player to a TV or a stereo.

1. Slid the AV in/out button at the “out” position.
2. Connect one end of the audio/video cable’s black (1/8” stereo plug) plug into the unit’s DVD AUDIO OUT jack, and connect the other end to the AUDIO INPUT jacks on your TV or Monitor (white = left channel, red = right channel).
3. Connect the audio/video cable’s yellow plug into the DVD VIDEO OUT jack on the back of the unit, and the other yellow plug to the VIDEO INPUT jack on your TV or Monitor.

9. Connecting Coaxial Output

The coaxial output of the unit can be used with an optional cable that has a stereo 1/8 inch male connector and a male RCA connector. The output of the cable can be aplied to any device which accepts a digital coaxial audio signal.

10. Specifications

Disc format: DVD/CD/MP3
Color system: NTSC/PAL
Screen size: 8''
Frequency response: DVD (PCM 96 kHz/24 bits): 20 Hz to 44 kHz
DVD (PCM 48 kHz): 20 Hz to 22 kHz
CD: 20 Hz to 20 kHz
Video output: 1.0 Vp-p/75 Ohm, unbalanced
Video S/N: Better than 35 dB
Audio S/N: Better than 35 dB
Power source: DC 9V 1.5A
Power consumption: 12 W
Operating temperature: 5~40°C (41~104°F)
Storage temperature: -20~60°C (4~140°F)
Operating humidity: 10~75%
Dimensions (W x H x D):7.87 X 5.90 X1.10inches
200 x 150 x 28mm
Battary Type: Li-ion

11. Rechargeable Battery Installation and Use

The player utilizes a set of long-life Li-ion batteries for portable power supply. The Li-ion battery pack is specially designed for your player, please consult your dealer for purchasing the battery pack. Li-ion batteries feature high storage capacity and low level of degradation. This means the Li-lon batteries doesn't have "Memory Effect" and thus can be recharged safely regardless of whether the battery is fully or only partially spent. Please fully charge the battery prior to first use.

NOTE: When the DVD player is used with the battery as a power source, ensure that the battery has been charged for at least five hours prior to connecting it to the DVD player. If you plan not to use the battery for an extended period of time (say, one week or longer), we recommend that you first fully charge the battery and store it away properly. For longer periods of storage, please recharge the battery

at least once every two months to maintain the battery in its best condition. Please under no circumstances short out the battery terminals, store the battery in a metal container, or leave the battery in a humid or damp environment. Ideally, store the battery in an airtight container with desiccant or other dehumidifying agent. Each full recharge takes approximately five-hours and one full charge can provide power the player for approximately 3 hours.During recharge, the red indicator will light on. Once fully recharged, the light will turn OFF. At this point you may remove the wall plug and stop charging.

Precautions related to Battery Recharge:

1. Once the battery has been fully spent, please immediately recharge (regardless of whether you plan to use battery power at once or not) in order to maximize battery life.
2. To charge the battery, please connect the power jack directly into the D1805 and leave the POWER switch in the off position.

Using and Maintaining your Rechargeable Batteries

1. Please make sure you always use **only** the AC transformer included with the player to recharge your batteries.
2. Recharge effiency will degrade when environmental temperatures drop below 50°F (10°C) or exceed 95°F (35°C).
3. Please remove battery from the player and store it properly if the player is not to be used for long time. During this period , please recharge the battery at least once two months to avoid irreparable damage to the battery.

Installing the Battery Pack:

1. First, make sure the player is in “Stop” mode and that the AC power supply has been disconnected.
2. Close the player cover.
3. Align the battery pack with the player module’s front edge.
4. Push the battery towards the rear of the player until it locks into position. The lock position is indicated by a click. The unit will fit snugly to the player.



Figure 45. Installing the DVD Player Battery

Removing the Battery Pack:

1. First, make sure the player is in “Stop” mode and the AC power supply has been disconnected.
2. Press the release button on the rear of battery.
3. Slide the battery towards the Front of the unit.



Figure 46. Removing the DVD Player Battery

AUDIOVOX ELECTRONICS CORP.

90 DAY LIMITED WARRANTY

Applies to Audiovox Video Products

AUDIOVOX ELECTRONICS CORP. (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 90 days from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) without charge for parts and repair labor.

To obtain repair or replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to tapes, discs, speakers, accessories, or electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 30 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

U.S.A. : AUDIOVOX ELECTRONICS CORPORATION, 150 MARCUS BLVD.
HAUPPAUGE, NEW YORK 11788 ● 1-800-645-4994

CANADA : CALL 1-800-645-4994 FOR LOCATION OF WARRANTY STATION SERVING YOUR AREA

128-5556C

For Customer Service
Visit Our Website At

www.audiovox.com

Product Information, Photos,
FAQ's Owner's Manuals

© 2003 Audiovox Electronics Corp., 150 Marcus Blvd., Hauppauge, N.Y. 11788

128-6920